

705 - WASHINGMACHINE CLEANER

TECHNICAL DATA SHEET | NORDICARE

Household care

NORDICARE WASHING MACHINE CLEANER is a water-based, mildly acidic specialty cleaner for cleaning and maintenance of washing machines. The product is intended for use in empty household washing machines and helps remove residues and deposits from internal machine surfaces as part of regular appliance care.

Key Benefits

- Designed for cleaning and maintenance of washing machines.
- Helps remove detergent residues, deposits and odour-causing build-up from internal machine parts.
- Mildly acidic cleaning profile based on citric acid.
- Contains non-ionic and amphoteric surfactants to support cleaning performance

Application area

For smooth leather and hide surfaces such as furniture, handbags, briefcases and similar leather articles. Not suitable for suede. The product may darken very light leathers. Always test on a small, inconspicuous area before full application and treat the whole surface at once to avoid blotches.

Instructions

Shake well before use. Wipe the leather with a damp cloth. Apply LEATHER SOAP to another damp cloth and wipe the leather surface lightly without rubbing. Treat the whole surface at once, allow to dry, and polish with a soft, clean cloth.



Conditioning

1000 ml (12 units/box)

Document control

Document no.: TDS-705
Product: Washingmachine Cleaner
Version: 01
Revision date: 06.08.2026
Prepared by: Technical Department

Declaration

Contains: 5% natural soaps, water, bis (8-hydroxyquinolium) sulphate and Benzisothiazol-3(2H)-one.

Safety information

WARNING

Causes serious eye irritation. Keep out of reach of children. Wash thoroughly after handling. Wear protective gloves and eye protection where there is risk of contact or splashing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses. If eye irritation persist: Get medical advice/attention.